



INSTALLATION INSTRUCTIONS XS/XM CHASSIS AIR FILTER GUARD SET

TOOLS REQUIRED: * 5/32" Sharp Drill Bit * Ice Pick/Scribe Tool * 2.5mm Allen Key * 7mm Socket or Wrench

***Estimate time of installation: 30-45 mins**

- 1.) Completely read instructions before starting.
- 2.) Take your time.
- 3.) Before removing OEM air filter assembly use each air filter guard as template to mark hole locations on right and left side of OEM air filter screen assembly.
- 4.) Mark center of each hole with ice pick/scribe tool.
- 5.) Remove OEM air filter screen assembly on both sides
- 6.) Drill holes with sharp 5/32" drill bit.
- 7.) Deburr holes if needed. Surface must be flush so air filter guard sits flush.
- 8.) Install air filter Guards to each air screen assembly with provided fasteners.
- 9.) Tighten fasteners evenly.
- 10.) Reinstall air filter assemblies to airbox.

Please call or email if you need specific technical help
(774) 849-5097/info@rpmcomposites.com.